


**GK-74** Series

#### ● 上彈匣步驟及注意事項 Steps and attentions for up loading magazine

步驟1.請確實卡至定位

Step1. Make sure they connect to the place \_\_\_\_\_



少職2.同上推 Step2. Push up

無彈不擊發 Select "Fires when BBs empty"




#### 取消無彈不擊發時注意事項

Attention when cancel "Fires when BBs empty" function

#### 請勿碰撞其他組件

Do no hit other components





# WARNING!

- 請務必戴上護目鏡等護眼用具
- 請勿射擊人或動物
- 隨意用BB槍開玩笑可能會觸及法律
- 嚴禁望向槍口
- 請將槍□朝向安全的地方
- 射擊時無論遠近,隨時確認射擊區內是否有行人或車輛經過
- 避免任意不經意地扣處扳機
- 除非完成射擊準備,否則切勿將手指放入扳機
- 不用或搬運時,請務必放置於槍盒等容器內
- 請存放在兒童拿不到的地方
- 禁止擅自改造或加強槍枝結構
- 非射擊時請將選擇鈕切換到保險位置
- 未成年兒童請由家長陪同下使用
- Always wear eye protective gear.
- Never aim or shoot a person or animal as the target.
- You may be punished if you are shooting for a practical joke.
- Never look into the gun muzzle.
- Always direct the muzzle towards a safe direction.
- Never shoot the air gun at places where people and cars pass cross.
- Avoid pulling the trigger carelessly.
- Please put away your fingers from the trigger, except when you are ready to shoot a target.
- Always put the gun in a case or bag when you are carrying it.
- Store the gun at places out of reach by children.
- Adult supervision is required for any person under the age of 18.





Don't fill in BBs over 48 rounds.

#### 勿放置高溫環境40℃以上 Don't place magazine at temperature above 40 ℃ environment.



### 塗抹高濃度砂油

Apply high viscosity silicone oil.

瓦斯裝填過量,會導致全自動射擊不順暢


If gas filled with excessive, will result in auto fire is not smooth.

- 充氣時間勿超過**5**秒 Don't fill over **5** seconds while gas filling.
- 隨時彈匣內要保有瓦斯 Remain gas in the magazine anytime.
- 請使用12Kg瓦斯 Only use 12KG Green gas.

GHIK


#### 金屬磨擦面,上油潤滑

Lubricate with oil on the rubbed metal surface.





## **GK-74** Series



1F, No.49, BO-AI 3 Rd, ZHONG LI City, TAOYUAN COUNTY 32041 TAIWAN, R.O.C. Te1: 886-3-4278783 Fax: 886-3-4278496 www.ghkairsoft.com Email:ghk@ghkairsoft.com

