

Armee Universal Gewehr Series





WARNING!


警告

- ●請務必戴上護目鏡等護眼用具
- ●請勿射撃人或動物
- ●隨意用BB槍開玩笑可能會觸及法律
- ●嚴禁望向槍口
- ●請將槍口常向安全的地方
- ●射擊時無論遠近,隨時確認射擊區内是否有行人或車輛經過
- ●避免任意不經意地扣處扳機
- ●除非完成射擊準備,否則切勿將手指放入扳機
- ●不用或搬運時,請務心放置於槍盒等容器内
- ●請存放在兒童拿不到的地方
- ●禁止擅自改造或加強槍枝結構
- 非射擊時請將選擇紐切換到保險位置
- ●未成年兒童請由家長陪同下使用
- •Always wear eye protective gear.
- ●Never aim or shoot a person or animal as the target.
- •You may be punished if you are shooting for a practical joke.
- Never look into the gun muzzle.
- Always direct the muzzle towards a safe direction.
- •Never shoot the air gun at places where people and cars pass cross.
- •Avoid pulling the trigger carelessly.
- •Please put away your fingers from the trigger, except when you are ready to shoot a target.
- •Always put the gun in a case or bag when you are carrying it.
- •Store the gun at places out of reach by children.
- •Adult supervision is required for any person under the age of 18.




操作說明 (Instruction)

- ●填彈器與彈匣保持平行填彈。Keep parallel angle between loader and magazine.
- ●裝填BB彈請勿超過36發。 Do not load bbs over 36 rounds.




●禁止由上方填彈,請使用原廠 專用填彈頭。 Probibit reloading directly above

Prohibit reloading directly above. Be sure to use original loader tip.




●此區請勿撞擊 Do not strike this area.





板機盒取出方法 (Trigger Box Removal Method)



https://youtu.be/77f28nTt-bI

- 1 上膛。 Reload.
- 2 向內擠壓著凹糟不放。 Squeeze on the groove inward.
- 3 將固定銷向內壓到底。 Push the back sling swivel to the end.
- 4 將後托塊取出。 Remove the butt plate.
- 5 向內擠壓著固定塊不放。 Squeeze on the fixing block.
- 6 將固定銷向外拔出。 Pull out the sling swivel.
- 7 將板機盒取出。 Remove the trigger box.
- ★板機盒不可在槍機後定時取出 Trigger box cannot be taken out in bolt lock condition.
- ★將板機盒取出時,請注意擊鎖位置是否為待發位置。
 Please note if hammer is on standby position before removing the trigger box.
- ★如有問題可至官網觀看分解 影片。 Please refer to video from


Please refer to video from our official website if you have disassemble question.



各部位零件保養 (Maintenance for inner parts.)


●紅圈處用針車油保養

Apply machine oil in the red circle part.



●槍機O環保養

Apply silicone oil on the bolt o-rings.




Apply high viscosity silicone oil.



各部位零件保養 (Maintenance for inner parts.)

- ●請使用0. 25克以上重量, 電槍規格之BB彈。 Please use bbs weight above 0.25g, for AEG's specification.
- ●長期不使用請勿裝填BB彈。 Stop feeding bbs if you do not continue use it.
- ●請勿放置超過40℃以 上之高溫環境。 Do not place magazine at environmental temperature above 40 degrees Celsius.
- ●隨時彈匣內要保有瓦斯。 Remaining gas in the magazine anytime.






瞄準鏡歸零方法 (Method of Zero the Scope)

★調整瞄準鏡,請依下列步驟調整。

Please refer to the steps of aim scope adjustment below.




★歸零時請調整中間螺絲(紅色部份) 請勿旋轉外部固定座(黑色部份)。 Please adjust the middle knob (red color part), do not rotate the external fixed base (black color part).

- 將二個調整螺絲放鬆。
 Loosen both adjustment knobs.
- 2 先調整好準星左右方向。 Adjust the horizontal direction (knob on right side) of sight first.
- 3 再調整準星上下方向。 Then adjust the vertical direction (knob on the below side) of sight.
- ★不可先調整準星上下方向, 會有歸零困難的問題。 Do not adjust the vertical direction of sight before zero the scope.

選購零件 (Parts Options)

- ●低初速活塞(使用12公斤瓦斯,1J) (AUG-15-L) Low muzzle version nozzle (with 12kg gas,1 Joule).
- ●日規版活塞(使用8公斤瓦斯, 1J) (AUG-15-1J)
 Japanese version nozzle (with 8kg gas,1 Joule).
- ●高初速版活塞(使用12公斤瓦斯) AUG-15-H High muzzle velocity version nozzle (with 12kg gas).







選購零件 (Parts Options)

●戰術鏡軌提把

Tactical mount bridge.




●前戰術護木+戰術鏡軌提把+16吋槍管組 Front tactical handguard + tactical mount bridge + 16" barrel set.






選購零件 (Parts Options)


●14吋槍管組 14" Barrel set.





●16吋槍管組 16" Barrel set.



●20吋槍管組 20" Barrel set.









No.19, Ln. 210, Gong 5th Rd., Longtan Dist, Taoyuan City 32559, Taiwan(R.O.C) Tel:886-3-4707602 Fax:886-3-4708902 www.ghkairsoft.com Email:ghk@ghkairsoft.com

